

SANDBLASTING CABINET - M PRESSURE SERIES

120 V / 208-230 V / 240 V / 460 V / 575 V



- Warranty
- Safety
- Operation

- Service Parts
- Accessory Information
- Registration Form



INSTRUCTION MANUAL

TABLE OF CONTENTS

	Page
NOTICE TO PURCHASERS - SAFETY AND WARNING	3
DANGER AND WARNING LABELS	4
PERSONAL SAFETY - UNIT USE AND CARE - GENERAL SAFETY RULES.....	5
INTRODUCTION - INSTALLATION - PNEUMATIC CONNECTION	6
ELECTRICAL CONNECTIONS -CONNECTIONS TO CABINET AND DUST COLLECTOR.....	7
PROPER AIRJET/NOZZLE COMBINATIONS - VERIFY INSTALLATION.....	8
OPERATION	10
HOW IT WORKS.....	11
SHUT DOWN - CHANGING THE MEDIA	12
RECLAIMER.....	13
MAINTENANCE CABINET AND DUST COLLECTOR.....	14
MAINTENANCE CABINET & PRESSURIZED VESSEL.....	15
PERIODICAL ADJUSTMENTS OF THE DCT1000 TIMER CONTROLLER.....	16
DCT1000 TIMER CONTROLLER.....	17, 18
NOZZLE MAINTENANCE.....	19
AR7 ASSEMBLY - DISASSEMBLY INSTRUCTIONS & ADJUSTMENTS	20, 21
TROUBLESHOOTING.....	22 to 27
SCHEMATIC OF UNIT - EXPLODED VIEW & PARTS.....	28
RECYCLING SYSTEM - EXPLODED VIEW & PARTS LIST	29
HOSES, COUPLINGS & NOZZLES - EXPLODED VIEW - NOZZLES TYPES.....	30, 31
AIR PRESSURE MANIFOLD - STANDARD ½" PIPING	32
AIR PRESSURE MANIFOLD - STANDARD ½" PIPING FOR PLASTIC MEDIA OPTION	33
AIR PRESSURE MANIFOLD - OPTIONAL 1" PIPING	34
PRESSURE VESSEL - EXPLODED VIEW & PARTS	35
OPTIONAL ROTARY TABLE & DOOR SWITCHES.....	36
OPTIONAL GUILLOTINE DOOR	37
AR7 REGULATOR & DEPRESSURIZING SYSTEM - EXPLODED VIEW & PARTS.....	38
BAGHOUSE DUST COLLECTOR - GENERAL PARTS LIST.....	39
CARTRIDGE DUST COLLECTOR - GENERAL PARTS LIST	40
FAN MOTOR & SUCTION HOSE	41
FOOT PEDAL & NO-CONTACT FOOT PEDAL (OPTIONAL)	42
RECOMMENDED SPARE PARTS	43
M PRESSURE PNEUMATIC DIAGRAM.....	44
ELECTRICAL SCHEMATICS	45 to 52
REFERENCE LIST FOR M-SERIE DCM 50 TO 330 & 600 TO 1800	53
IST LIMITED WARRANTY	54
IST WARRANTY REGISTRATION	55
ABOUT THE COMPANY	56

NOTICE TO PURCHASERS AND USERS OF OUR PRODUCTS AND THIS INFORMATIONAL MATERIAL

The products described in this material, and the information relating to those products, is intended for knowledgeable, experienced users of abrasive blasting equipment.

No representation is intended or made as to the suitability of the products described herein for any particular purpose of application. No representations are intended or made as to the efficiency, production rate, or the useful life of the products described herein. Any estimate regarding production rates or production finishes are the responsibility of the user and must be derived solely from the user's experience and expertise, and must not be based on information in this material.

The products described in this material may be combined by the user in a variety of ways for purposes determined solely by the user. No representations are intended or made as to the suitability or engineering balance of the combination of products determined by the user in his selection, nor as to the compliance with regulations or standard practice of such combinations of components or products.

It is the responsibility of the knowledgeable, experienced users of the products mentioned in this material to familiarize themselves with the appropriate laws, regulations and safe practices that apply to these products, equipment that is connected to these products and materials that may be used with these products.

It is the responsibility of the user to insure that proper training of operators has been performed and a safe work environment is provided.

Our company is proud to provide a variety of products to the abrasive blasting industry, and we have confidence that the professionals in our industry will utilize their knowledge and expertise in the safe efficient use of these products.


SAFETY AND WARNING

GENERAL SAFETY

1. Carefully inspect the shipping carton for any signs of transport damage. The damage to the carton often indicates possibility of transport damage to the equipment inside.
2. Carefully remove your IST SANDBLASTING CABINET from the shipping carton and skid.
3. Check your equipment immediately to ensure that it is free of transport damage. Report any transport damage to the carrier without delay for possible claim procedures. International Surface Technologies inc. is not responsible for damage to equipment after it leaves our warehouse.
4. Check the equipment and compare it with the parts you have received. If any parts are missing, contact the supplier you purchased the equipment from.

Before operating the IST SANDBLASTING CABINET, read this Instruction Manual completely. All IST products are engineered and manufactured to the highest performance standards and have been subjected to detail testing before shipment from the factory.

DANGER AND WARNING LABELS



000000

1. Wear breathing mask
2. Observe warnings at all times.
3. Read the Instruction Manual carefully.
4. Wear rubber gloves.
5. Wear protective eyewear before use
6. Wear earing protection before use

WARNING

« READ ALL INSTRUCTIONS » Failure to follow the SAFETY RULES identified by a BULLET (●) symbol listed BELOW and other safety precautions may result in serious personal injury.

« SAVE THESE INSTRUCTIONS »

GENERAL SAFETY RULES

- **KEEP WORK AREA CLEAN.**
- **KEEP CHILDREN AWAY.** Do not let visitors come in contact with the equipment. All visitors should be kept away from the work area.

PERSONAL SAFETY

WARNING

SANDBLAST CABINET MAY EMIT POTENTIALLY HAZARD DUST AND AIRBORNE CONTAMINANTS DURING OPERATION. YOU MUST WEAR APPROPRIATE BREATHING PROTECTION AT ALL TIMES WHILE OPERATING OR STANDING AROUND THE UNIT.

- **GUARD AGAINST ELECTRIC SHOCK.** Non-skid footwear is recommended where damp or wet ground may be encountered. A ground fault circuit interrupter protected power line must be used for these conditions.
- **DRESS PROPERLY.** Do not wear loose clothing or jewelry. They can be caught in the moving parts. Wear protective hair covering to contain long hair.
- **USE SAFETY EQUIPMENT. WEAR SAFETY GOGGLES** or glasses with side shields.
- **WEAR A DUST PROOF MASK.**
- **STAY ALERT. USE YOUR COMMON SENSE.** Concentrate on what you are doing. Do not operate the unit when you are tired or under the influence of drugs.
- **DO NOT OVERREACH.** Keep proper footing and balance at all times.
- **BEFORE CONNECTING THE UNIT** be sure the power is the same as that specified on the nameplate of the Sand Blasting Cabinet. With power greater than that specified on the nameplate can seriously injure the user – as well as damage the Unit.
- **BEFORE STARTING TO WORK** you must wear earing protections, efficient for 80 dB or more.

UNIT USE AND CARE

- **DO NOT FORCE THE UNIT.** It will perform better and safer at the rate for which it was designed.
- **THE USE OF ANY OTHER ACCESSORIES** not specified in this manual may create a hazard.
- **CLOSE THE MAIN BREAKER SWITCH BEFORE SERVICING** or when not in use.
- **DO NOT ALTER OR MISUSE THE UNIT.** These units are precision built. Any alteration or modification not specified is misuse and may result in a dangerous situation.

Only trained repairmen should attempt (●) ALL REPAIRS, electrical or mechanical. Contact the nearest IST a repair service facility. Use only IST replacement parts; any other parts may create a hazard.

ENVIRONMENTAL CONDITIONS FOR WHICH THE EQUIPMENT IS DESIGNED

- Indoor location
- Altitude 6,562 ft max
- Ambient temperature: 104 °F (40 °C) max
- Relative humidity: 80 %
- Main supply voltage fluctuation +/- 10 %
- To use with noncombustible dust only

INTRODUCTION

Welcome to the IST[®] family of sandblasting products. This booklet contains helpful information and acquaints you with the operation and maintenance of your equipment. Please read carefully and follow our recommendations to assure trouble free operation. If you have any questions, please do not hesitate to contact your distributor or our technical service.

INSTALLATION

1. Unbolt the blast cabinet from the pallet. Attach a strap or a hoist to the eyelets located on the top of the machine and move it to its final location using a lift truck or a crane.
2. Make sure the cabinet is leveled and well grounded. Do not place on a wooden floor or a rubber mat, unless a ground wire has been installed. Check with a qualified electrician.
3. Place the system to the installation location.
4. Unwrap and remove the cabinet from the pallet.
5. Insure there is adequate space on both sides of the cabinet for full opening of part loading/unloading and maintenance access doors.
6. Insure that there is adequate space at both sides of the system for easy access to components such as the reclaimer and dust collector.
7. The dust collector should be located on a leveled area near the back of the cabinet, on the right side (while facing cabinet). Attach one end of the corrugated discharge hose to the outlet of the reclaimer and the other end to the inlet located at the bottom of the dust collector. Secure both ends with the supplied clamps. See dust collector section for more details.

All IST M series cabinets are equipped with a motorized dust collector ranging from 400 to 1,800 cfm.

PNEUMATIC CONNECTION

Connect your shop's air supply line to the air inlet. The hose should have a minimum of $\frac{1}{2}$ " inside diameter. Never use male-female quick couplings. Choose couplings that offer as little restriction to the airflow as possible.

To properly operate, your IST system use clean, dry air. Moisture or oil from the compressed air supply can contaminate the abrasive, and prevent it from flowing freely and cause inefficient blasting.



For detailed pneumatic connections, refer to pneumatic diagram page 44.

CAUTION If you use interlocking connections, secure them with pins. A connection that disconnects under pressure, could cause serious injury.

ELECTRICAL CONNECTIONS

Connect cabinet power supply cord to standard 120 V outlet.

Note: None-standard voltage is also available.



All electrical connections to the IST cabinet should be made by a qualified electrician and must comply to the codes, standards, and procedures specified by the local authority having jurisdiction.

The customer is responsible for providing appropriate disconnecting means adjacent to the equipment for each incoming power circuit.

For detailed electrical connections wiring requirements, overload and starter, Refer to electrical drawings on pages 45 to 53.



It is important to connect the IST system to an Earth Ground to bleed off static electricity, which may be generated while blasting. The Earth Ground may also reduce the discomfort an operator may experience when static electricity is discharged.


CONNECTIONS TO CABINET AND DUST COLLECTOR

	Dust Collector Model				
	DCM100	DCM600	DCM160/900	DCM230/1200	DCM330/1800
Fan Motor (hp)	1/2	1	Available from 2 to 10 hp		
Fan Motor (cfm)	400	600	900	1200	1800
Power Requirement	120 V /15 A	120 V /20 A	Available in 208-230V, 240 V, 460 V, and 575 V		

DCM Motor 120 V



DCM Motor 208-230 V, 240 V, 460 V, and 575 V



208-230 V, 240 V, 460 V and 575V Electrical Inlet

Main entry with fuse disconnect switch supplied by customer. Refer to Electrical Drawings on pages 45 to 53.

PROPER AIRJET/NOZZLE COMBINATIONS

AIR CONSUMPTION PRESSURE BLASTING SYSTEM

Nozzle I.D. ⁴	Units	WORKING PRESSURES (psi) ²											
		20	25	30	35	40	45	50	60	70	80	90	100 ⁰
^{1/8"}	cfm ¹	7	7	8	9	10	12	13	14	15	17	19	20
	lb/h ³	48	48	55	62	69	73	77	82	110	127	140	154
^{3/16"}	cfm ¹	15	16	18	20	22	24	26	30	33	38	41	45
	lb/h ³	94	101	114	127	140	153	166	192	220	243	268	297
^{1/4"}	cfm ¹	27	30	34	37	41	45	49	55	61	68	74	81
	lb/h ³	174	193	219	251	276	303	329	369	398	460	504	556
^{5/16"}	cfm ¹	42	46	53	57	65	70	76	88	101	113	126	137
	lb/h ³	254	278	320	345	394	425	462	528	680	756	832	910
^{3/8"}	cfm ¹	55	63	76	82	91	100	109	126	143	161	173	196
	lb/h ³	374	428	517	558	620	682	744	860	970	1080	1184	1296
^{7/16"}	cfm ¹	72	85	100	112	124	137	149	170	194	217	240	254
	lb/h ³	488	576	678	759	835	840	908	1160	1320	1476	1630	1782
^{1/2"}	cfm ¹	96	112	129	146	165	179	195	224	252	280	309	338
	lb/h ³	629	734	845	976	1103	1197	1305	1500	1700	1890	2088	2277
^{5/8"}	cfm ¹	173	195	212	239	260	282	308	356	404	452	504	548
	lb/h ³	1081	1219	1325	1470	1600	1716	1875	2140	2422	2690	2973	3250
													3623

⁰ Optimal pressure

¹ psi: Pressure at nozzle in pounds per square inch

² cfm: Compressed air required in cubic feet per minute

³ lb/h: Abrasive consumption in pounds per hour

⁴ Nozzle I.D.: nozzle interior diameter

VERIFY INSTALLATION

- Check that all pipe and hose connections are tightly fastened and air tight.
- Check that all electrical box covers are securely installed.
- Check that the dust drum under the dust collector is sitting firmly and is center (if equipped).
- Turn the cabinet power switch to the "On" position. The cabinet lights will power on and the dust collector fan and the reclaimer will start.
- Set the blast air pressure regulator to the desired pressure.
- Insert both hands into the cabinet gloves, take the gun and press the foot pedal. Blasting will start, wait a few second and the blast flow will stabilize.
- Turn the cabinet power switch to the "Off" position. Light will turn off and the dust collector fan and reclaimer will stop.

CAUTION Disable and lock out power sources before performing service or maintenance work. Do not look into the fan outlet to determine the correct motor rotation. Check that the fan exhaust is clear of tools and free of debris before checking fan rotation. To avoid personal injury, stay clear of the fan exhaust.

LOADING ABRASIVE MEDIA**WARNING**

Your suction cabinet is designed to operate efficiently with most **recyclable abrasive media** on the market. However, certain types such as sand, recycled glass or silica are not recommended and should not be used in our blast cabinet.

These abrasives generate very fine dust that may block the bag's pores, obstruct the ventilation system and cause dust accumulation inside the cabinet while in use. Instead, use reclaimable abrasives such as glass beads, aluminum oxide steel grit or plastic media.

For better results for the reclaiming process, **please call one of our technical representatives** if you have to use a different **type of abrasive** from the one your equipment has been set for at the factory.

Manufactured Abrasives

NAME	TYPE	SHAPE	HARDNESS SCALE	DENSITY PDS/CUFT	CONTENT SILICA	DUST FACTOR	MESH SIZE	REUSE FACTOR	AVAILABILITY
Aluminium Oxide	Oxide	Irregular	8 Mohs	120	None	Low	6-600	Good	Good
Silicon Carbide	Carbide	Angular	9 Mohs	100-110	None	Low	6-600	Good	Good
Glass Beads	Silica	Spherical	5-6 Mohs	100	0 free Silica	Low	20-325	Good	Good
Plastic Grit	Polyurethane	Angular	3-4 Mohs	58-60	None	Low	12-80	Good	Good
Chilled Iron & Steel Grit	Metallic	Angular	40-68 Rc Rockwell C	250	None	Very Low	18-200	High	Good
Chilled Iron & Steel Shot	Metallic	Spherical	40-68 Rc Rockwell C	250	None	Very Low	7-200	High	Good

LOADING ABRASIVE MEDIA

Follow these steps to avoid locking the drain at the bottom of the cabinet when adding a brasic media.



1. Turn on the cabinet to activate the vacuum system.

2. **SLOWLY add approximately half a bag of abrasive media through the grating inside the cabinet.**



NOTE: Some cabinets can hold more than half a bag when added gradually.

OPERATION

Turn on compressed air and turn on lightning and motor with the power switch. Compressed air must be clean, dry, and oil free.

1. When using the unit, air pressure (**should not exceed 110 psi**) Place the part to be treated inside the cabinet. The parts must be free of oil, grease, and moisture. Close and latch the cabinet load doors.
2. After closing the door, insert your hands into the two front glove openings. The blasting gun should be held firmly in one hand and the part to be treated in the other hand. The stream of abrasive should be oriented to the bottom of the working chamber.
3. Depressing blast control pedal will release compressed air flow to the blast gun. Hold the gun or nozzle at a 90° angle to the part at a distance that produces the fastest results. The reclaimer screen will require periodic cleaning. The frequency of cleaning will depend on the volume of debris produced. See maintenance section at page 15 for more information.
4. After the media has blasted the part, the reclaiming system vacuums up the abrasive, dust and foreign material through the conduit at the bottom of the cabinet to the reclaimer. The reusable abrasive is separated from the dust and foreign material and is returned to the storage hopper for reuse. The dust bag or the cartridges of the dust collector, filters the dust and fine particles. Larger pieces of contaminants are trapped in the hopper's screen drawer.



HOW IT WORKS**PRESSURE CABINET****PRESSURE SYSTEM**

SHUT DOWN

1. Release the foot treadle. The blast will stop.
2. Once cleaning is finished, await 10 to 15 seconds before turning off the power switch and opening the door of the cabinet in order to allow the evacuation of dust in suspension.
3. Open the door and remove the treated parts from the blast cabinet.
4. Close air supply.
5. Turn power switch to the "OFF" position.
6. Empty the dust collector waste drum (Optional part). Replace the drum squarely on the dust drum platform and centered under the cover. The dust drum and cover must create an airtight seal.
7. Shake bags of your dust collector (disregard if you system is equipped with optional automatic bag shaker or a cartridge-type dust collector).

CHANGING THE MEDIA

When changing from one type or size of media to another, it can be extremely important to clean out the blast and recovery hoses, storage hopper, and the cabinet interior thoroughly to avoid contamination of the new media.

During normal sandblasting operation, the media should be replaced completely every 8 hours.

CLEANING THE SYSTEM

1. Turn the system off.
2. Adjust pressure at 20 psi
3. Remove nozzle
4. Open sandblasting valve
5. Close ball valve on pressure vessel
6. You need a container large enough to collect used media. Place the container inside the cabinet and place the sandblasting hose inside the container.
7. Press on foot pedal

All media will be expelled from the system through sandblast hose. **Make sure pressure does not exceed 20 psi.** When cleaning is done put back everything in place.

1. Release foot pedal
2. Screw nozzle in place
3. Open ball valve on pressure vessel
4. Close sandblasting valve
5. Adjust pressure at desired position
6. Turn system on


RELOADING WITH NEW ABRASIVE MEDIA

Refer to Abrasive Loading procedure on page 9.

RECLAIMER


RECYCLER INFORMATION

Although the recycler is factory set, it is possible to increase the amount of fine dust to be sucked up by the dust collector. There are two methods to change those settings:



1. Adjustment of the SBR 1/8 " X 2 " rubber band

This adjustment will influence the quantity of dust that will be evacuated to the dust collector. Proceed step by step, moving down the rubber band 1/4" at the time, covering or uncovering the slots behind it. **A wider opening will draw up more dust to the dust collector; a smaller opening will reduce that quantity. The equipment has to run for approx. two (2) hours before any changes can be noticed.** Repeat as needed.



2. Adjustment of the telescopic tube, inside of recycler


If, after a few tests, the rubber band adjustments should prove to be insufficient, you will have to proceed to the telescopic tube adjustment. This will be necessary if you have to change the abrasive type or granulometry. Proceed step by step, moving the tube up or down, 1 inch at the time. **The equipment has to run for approx. two (2) hours before any changes can be noticed. Moving the tube downward will increase the quantity of dust drawn up by the dust collector, moving it up will decrease that quantity.**

AR7 ABRASIVE REGULATOR



The AR7 Abrasive Regulator is located at the bottom of the pressure vessel. It must be set according to the abrasive type in use. Turn the handle approx. 1/4 of a turn clockwise at the time to decrease the quantity of abrasive to the nozzle and counterclockwise to increase it. You must wait 15 seconds before any changes can be noticed. Adjustment to decrease the quantity has to be made while the pressure vessel is in operation.


Note : Too much abrasive in the sandblasting jet will cause it to be jerky and less efficient, not enough will cause an inconstant sandblasting.

MAINTENANCE CABINET AND DUST COLLECTOR**DAILY MAINTENANCE & OPERATION**

1. Check both the quantity and quality of abrasive frequently. If required, clean out the system and reload with new media.
 2. To avoid blockage, empty and clean the reclaimer's screen drawer regularly.
 3. Check for wear on all parts in direct contact with the blasting action: nozzle, gloves, window, plastic shield, air-jet, gun etc. Special attention must be given to nozzle, nozzle ring and rubber protector to avoid premature wear of gun. Make sure ventilation inlet is always free of obstruction.
 4. Empty dust barrel or dust collector's bottom hopper regularly.
- 5. Baghouse Dust Collector:** after each use, turn off the impeller and shake bags inside the dust collector. Never shake bags while the cabinet is running. Never wash bags, instead use compressed air, **blowing from the outside to the inside of the bag**, (the opposite would clog the bag's pores and make it unusable).
- 6. Cartridge Dust Collector:** verify the values on the DCT1000 and replace cartridges when indicated. See next page for details.

WEEKLY

- **Sandblast Nozzle:** check the I.D. using a drill bit that is 1/8" wider than the original diameter of the nozzle. If the drill bit fits in, replace the nozzle. A worn nozzle will cause a drop of abrasive pull and velocity.
- **Abrasive Hose:** check abrasive hose for wear. It has to be changed before it gets any perforation. Give a special attention to parts of the hose that are curved.
- **Couplings and Gaskets:** check on a regular basis the hose couplings and gaskets for wear.
- **Media filters:** replace bags when the dust collector is unable to evacuate the dust cloud from the cabinet.




ISTblast is a registered trademark of
International Surface Technologies
Hwy. 640 Industrial Park
Terrebonne, Quebec
J6Y 0P6 Canada

1050 Des Forges Street
Hwy. 640 Industrial Park
Terrebonne, Quebec
J6Y 0P6 Canada

T: 877 629-8202
info@istsurface.com

IST International Surface Technologies

MAINTENANCE CABINET & PRESSURIZED VESSEL



- DAILY**
1. Auditory inspection around the pressurized vessel to identify air leaks

MONTHLY

1. Proceed to Bubbling test (see below)
2. Disassembly and inspection of the pressurized vessel
3. Disassembly and inspection of the sandblast valve

BUBBLING TEST

- The Bubbling Test identifies air leaks in the pressurized vessel (usually from the plunger or plunger's O-Ring)
- a. Start the cabinet dust collector
 - b. Press the foot pedal to start blasting
 - c. Open the debris drawer door
 - d. Remove the debris drawer and observe the bottom of the hopper for bubbles:
 - e. If bubbles form, it means that the phenomenon of under pressure is observed and that air is infiltrating through the sand valve


MAINTENANCE OF PRESSURIZED VESSEL

WITH THE VESSEL DEPRESSURIZED

Dismantle the storage hopper above the pressurized vessel and check the wear condition of the sealing components inside the vessel:


ID	Parts #	Description	Qty
1	610040	PLUNGER	1
2	618205	PLUNGER O-RING	1
3	630671	1" PA MNPT SACRIFICED PLUGS	2
4	605011	5/16" BN2-5 BORON CARBIDE NOZZLE	1
5	608611	AUTO-DEPRESSURIZATION VALVE	1
	608612	DIAPHRAGM FOR DEPRESS. VALVE	1

Quick Depressurization System



PERIODICAL ADJUSTMENTS OF THE DCT1000 TIMER CONTROLLER

DCT1000 TIMER CONTROLLER



MONITORING OF PRESSURE DROPS

The DCT1000 monitors the static pressure differential between the clean and the dirty sides of cartridge filters – so-called pressure drop. As the filters load with dust, the resistance to air flow increases, and so does the pressure drop.


Brand new cartridge filter set will indicate a process value between **0.2** and **1.0**. During the first few hours of operation, dust will build up on the cartridges' pores in order to reach their optimal filtration capacities – this process is commonly referred to as the "dust cake".

High limit : 3.5
Low limit : 2.0

Once the new cartridges are saturated with a dust layer, the normal operating value should be between **2** and **3.5** – which are the initial **Low Limit** and **High Limit** defined in the DCT1000.

High limit / Low limit

DCT 1000
Pressure module
#908704



CARTRIDGE CLEANING


When the process value reaches the **High Limit**, the cleaning cycle starts emitting a series of pulses of air through each cartridge in order to dislodge exceeding amount of dust buildups. Pulses of air can be heard when the cycle is on.

During the cleaning cycle, the pressure drops should decrease on each pulse until it reaches the **Low Limit** which interrupts the cleaning cycle.

High limit



REVERSE PULSE CLEANING



Low limit




DCT1000 TIMER CONTROLLER (CONT'D)

INITIAL VALUES

High limit : 3.5
Low limit : 2.0

Stagnant pressure drop



PERIODICAL ADJUSTMENTS

Follow the procedure below in order to extend the life span of your cartridge filters while maximizing the filtration capacity of your dust collector.

When the cleaning process of the cartridges is no longer able to reach the **Low Limit** value, the cleaning cycle will run continuously.

At that moment, it is advised to increase the **Low Limit** and **High Limit** in order to extend the life span of the cartridge media to a certain limit.

Start increasing the **Low Limit** and **High Limit** of the cleaning process by 2 decimals above the stagnant value. For example, if the cleaning cycle runs continuously and the process value on the DCT1000 indicates **2.2**, set the new **Low Limit to 2.4** and the new **High Limit to 3.9**.

NEED TO REPLACE CARTRIDGES

FINAL VALUES

High limit : 8.5
Low limit : 7.0

NEW VALUES

High limit : 3.9
Low limit : 2.4

Keep increasing moderately until your cartridges are incapable of reaching a **Low Limit of 7.0**. At that moment, it is time to change your cartridge filters and reset your process values to initial **Low Limit 2.0** and **High Limit 3.5**.



REPLACEMENT OF CARTRIDGE FILTERS

Change all your cartridge filters at the same time, regardless of their individual condition.

If you notice a damaged cartridge, immediately replace all your cartridge filters at once – if a cartridge filter is damaged and/or perforated, it may cause severe damage to your impeller and mislead the DCT1000 timer controller in its ability to control the cartridges cleaning cycles properly.

Refer to the owner's manual for parts number and changing procedure.

DCT1000 TIMER CONTROLLER (END)

SETTINGS

Use the (Select) and (Up) (Down) keys you will be able to change the parameters.

Note: Your unit has been programmed in the factory, if you change some settings during operation be sure to write down the initial values.

PARAMETERS

Process: Value displayed during operation of the fan (inches of water restriction cartridges).

Last Output: Number of active solenoid (this value can not be changed because the system auto-detects the number of active coil connected to the card).

Time Off: downtime between each pulse (value 10 seconds).

ON Time: Time pulse valves (value 250 milliseconds).

High Limit: The value to which the cleanup will begin (value between 2.5 and 3.5).

Low limit: The value to which the cleaning will stop automatically (value between 1.5 and 2.5).

High Alarm: Value must be reached to activate alarm (High limit value 2).

Low Alarm: Value must be reached to activate alarm (Low limit value 0).

Cycle Delay: This value is to operate in manual mode (value = 0).

Down Time Cycles: This value is to operate in manual mode (value = 0).

Auto Alarm Reset: This value is to operate in manual mode (value = 0).



BLAST NOZZLE INSPECTION - MAINTENANCE SCHEDULE

Nozzle: check the nozzle regularly for wear using a drill bit
1/8" larger than the **original nozzle diameter**

IT GOES THROUGH



**WORN NOZZLE
TO BE REPLACED**

DOES NOT GOES THROUGH






NOZZLE IN GOOD SHAPE

The inside diameter should never exceed 1/8" of wear



AR7 ASSEMBLY - DISASSEMBLY INSTRUCTIONS



1. Close Completely the Ball Valve (1)
2. Release pressure by turning the Pressure Regulator (2) until the pressure displayed on the Pressure Gauges (3) fall to zero.
3. Turn the AR7 lever clockwise until end of course.
4. Unplug the Quick Connect (4) and unscrew the hose swivel insert (5)
5. Now you can remove the AR7 by unscrewing it from the adaptor.
6. Loosen the 4 bolts (6) holding the 2 parts of the housings and separate them.
7. Remove the regulation tube (7) and replace it with a new. Before reassembling the AR7 check the gasket (8) and replace it if necessary.
8. Replace the AR7 kit and restore the pressure to initial value if required.
Must be at 70 psi max.


ISTblast is a registered trademark of
International Surface Technologies

T: 877 629-8202
info@istsurface.com

1050 Des Forges Street
Hwy. 640 Industrial Park
Terrebonne, Quebec
J6Y 0P6 Canada

IST | International Surface Technologies

AR7 ABRASIVE METERING VALVE ADJUSTMENT




Follow the procedure below to adjust your abrasive media valve for the first time or when you change blast nozzle or blast media.

1. Open completely the media valve by turning the crank counterclockwise (see image 1)
2. Make three (3) complete turns clockwise to close the valve (see image 2).
3. Press on the remote control handle for approximately 10 seconds and observe the blast jet.
4. Keep closing or opening the valve, half turn at the time, until desired blast jet is obtained.

How to determine the ideal abrasive media flow.


- ✓ Ideal flow: The flow is constant, even, stable, white color and you can see through.
- ✓ Too much media in the flow: The flow is unstable, pulsating or jerky. Close the valve (Image 2), half turn at the time and check again.
- ✓ Not enough media in the flow: The flow is transparent and not powerful enough to produce desired result. Open the valve (Image 1), half turn at the time and check again.

AR7 ABRASIVE METERING VALVE - TROUBLESHOOTING

TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION
ABRASIVE NOT FLOWING DURING BLASTING (AIR ONLY)	The Pressure vessel is empty.	Depressurize the pressure vessel, add media and check again.
	The «Blast On / Air Only Switch» (if equipped) is set to «Air Only» mode and is preventing the abrasive from flowing.	Turn the switch to «Blast On» allowing the media regulator to release media in the push line.
	The Abrasive Regulator is closed or not properly adjusted.	Turn the adjustment crank counterclockwise, half turn at the time, to allow more media in the mix.
	 There is a blockage in the Abrasive Regulator.	Have a second qualified person to assist. Activate the control handle and ask a qualified person to alternate open/close the «choke valve» for 3-5 times until the obstruction is released. Minor obstructions, such as paint chips, a bit of wet abrasive or a piece of paper, will be forced through the Regulator and out the nozzle. Turn the Regulator back to the required blast setting and check if the obstruction has been removed. If the blockage persists, release the remote-control handle, depressurize the vessel and proceed to disassembling the Regulator and removing the blockage manually.
	The pressurized vessel has an air leak and the pressure inside the vessel is less than the one on the push line.	Check for air leaks (plunger seal, maintenance door, and/or quick-depress valve) and service your blast pot.
	The abrasive media is contaminated with humidity, which prevent it from flowing through the Regulator.	Empty your pressurized vessel from media, clean the reservoir through the maintenance door, and replace with new media. Consider servicing and/or adding air dryer and/or dessicant filter on your airline.
ABRASIVE STREAM TOO HEAVY OR THROBBING DURING BLASTING	Note : When Auto-depress systems first start up, they may throb for a while if there is an accumulation of abrasive in the blast hose from a previous operation. This is normal, and no corrective action is needed.	
	The Choke Valve is partially closed. The Abrasive Blaster should be operated ONLY with the Choke Valve fully open.	Open the Choke Valve and check again.
	The Abrasive Regulator needs adjusting.	Turn the adjustment crank clockwise to restrict media in the mix. If your unit is equipped with a Actuator that closes the Regulator when the unit is not blasting, be sure to adjust the Regulator only while blasting.
	The rubber tube inside the regulator is worn or ultimately pierced.	Disassemble the Regulator, clean any accumulation of media in it and change the rubber tube. If the rubber tube as a perforation, the media can flow freely in the Regulator and therefore can create wear on all the other inner mechanical parts. Proceed to a complete inspection of the push line before using the unit again.

***Note:** The first time automatic depressurization systems are started, they may pulsate for a while if there is an accumulation of abrasive in the blast hose during a previous operation. This is normal and no corrective action is necessary.



TROUBLESHOOTING

TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION
Excessive dust in the cabinet (poor visibility) and/or very dusty abrasive (inefficient)	 <p>Air intake behind the cabinet obstructed</p>	Check the trap above the cabinet to make sure it is open and clear
	<p>Clogged filter media:</p> <ol style="list-style-type: none"> 1. Dust barrel filled 2. Bags shaken during cabinet operating¹ 	<ol style="list-style-type: none"> 1. Empty the dust barrel as well as the connection hose connecting the barrel and the cyclone separator 2. Replace clogged bags²
	Dust collector fan motor connected upside down (blades turn upside down)	Reverse motor electric connection 
	Incorrect adjustment of the cyclonic separator (the dust recirculates in a loop instead of being evacuated to the dust collector and mixes with the abrasive) 	<ol style="list-style-type: none"> 1. If the material has changed since the cabinet was manufactured, contact an IST representative 2. If the material has not changed since the cabinet was manufactured, slightly open the rubber band around the cyclonic separator to increase the velocity, observe the results on the abrasive level after a few hours of blasting 

¹Never shake the bags while the dust collector fan is on. This forces dust to enter the pores of the media rather than lodge on the surface.


²Do not wash bags with water or by blowing compressed air through them. Both of these methods will damage the bags and make them obsolete.

TROUBLESHOOTING (CONT'D)

TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION
Excessive dust in the cabinet (poor visibility) and / or very dusty abrasive (inefficient)	<p>Non-recyclable abrasive³</p>  <p>Suction hose (behind the cabinet) is partially or completely blocked</p> 	Follow abrasive drain and cleaning procedures and replace with recyclable abrasive.
Suction hose outlet (behind the cabinet) partially or completely blocked	<p>Incorrect filling procedure: too much abrasive or poured too quickly.</p> 	Open the service door (1) and disconnect the abrasive suction hose (2) at the bottom of the hopper, remove the abrasive in excess and repeat the filling procedures properly.
	<p>Lack of cfm (problem with the dust collector) which causes the outlet to become progressively blocked.</p> 	Follow the procedures for resolving a dusty cabinet as described above.



³ Never use non-recyclable abrasive in IST cabinets, such as slag, silica sand, recycled glass, or other like them. IST cabinets are designed to be used exclusively with recyclable abrasive that generates a limited amount of dust. Ask your IST representative for more information.

TROUBLESHOOTING (CONT'D)

TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION
"Good" abrasive ends up in the dust container of the dust collector	Incorrect adjustment of the rubber band of the cyclonic separator	 <p>Cover gradually the holes with the rubber band to reduce the velocity flowing through the cyclonic separator</p>
Too much velocity (cfm) in the cyclone separator	The seal around the debris drawer is damaged or not properly installed	 <p>Check the gasket around the drawer to make sure it is tight and replace if necessary.</p>
	<p>a. The central tube of the cyclonic separator is not adjusted properly due to a change of abrasive</p> <p>b. The central tube of the cyclonic separator is perforated at the inlet of the separator</p>	 <p>Contact your IST representative</p>




⁴The center tube of the cyclonic separator is factory adjusted for the abrasive specified at the time of purchase. If the abrasive changes during operation, it may be necessary to readjust the inner tube to alter the movement and flow of air within the cyclonic separator.

TROUBLESHOOTING (END)

TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION																																																																																																																																																																																																																																																																												
Lack of abrasive in the mix (the nozzle blows mainly air)	<p>Air supply problem (using a quick connect or a connection that creates a restriction to the cabinet air supply)</p>  <p></p>	<p>Follow cabinet air connection guidelines (see chart page 8)</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="13" style="text-align: center;">WORKING PRESSURES (psi)²</th> </tr> <tr> <th>Nozzle I.D.</th> <th>Units</th> <th>20</th> <th>25</th> <th>30</th> <th>35</th> <th>40</th> <th>45</th> <th>50</th> <th>60</th> <th>70</th> <th>80</th> <th>90</th> <th>100^a</th> <th>120</th> </tr> </thead> <tbody> <tr> <td>1/8"</td> <td>cfm¹</td> <td>7</td> <td>7</td> <td>8</td> <td>9</td> <td>10</td> <td>12</td> <td>13</td> <td>14</td> <td>15</td> <td>17</td> <td>19</td> <td>20</td> <td>25</td> </tr> <tr> <td>1/8"</td> <td>lb/h¹</td> <td>48</td> <td>48</td> <td>55</td> <td>62</td> <td>69</td> <td>73</td> <td>77</td> <td>82</td> <td>110</td> <td>127</td> <td>140</td> <td>154</td> <td>192</td> </tr> <tr> <td>3/16"</td> <td>cfm¹</td> <td>15</td> <td>16</td> <td>18</td> <td>20</td> <td>22</td> <td>24</td> <td>26</td> <td>30</td> <td>33</td> <td>38</td> <td>41</td> <td>45</td> <td>55</td> </tr> <tr> <td>3/16"</td> <td>lb/h¹</td> <td>94</td> <td>101</td> <td>114</td> <td>127</td> <td>140</td> <td>153</td> <td>166</td> <td>192</td> <td>220</td> <td>243</td> <td>268</td> <td>297</td> <td>363</td> </tr> <tr> <td>1/4"</td> <td>cfm¹</td> <td>27</td> <td>30</td> <td>34</td> <td>37</td> <td>41</td> <td>45</td> <td>49</td> <td>55</td> <td>61</td> <td>68</td> <td>74</td> <td>81</td> <td>97</td> </tr> <tr> <td>1/4"</td> <td>lb/h¹</td> <td>174</td> <td>193</td> <td>219</td> <td>251</td> <td>276</td> <td>303</td> <td>329</td> <td>369</td> <td>398</td> <td>460</td> <td>504</td> <td>556</td> <td>666</td> </tr> <tr> <td>5/16"</td> <td>cfm¹</td> <td>42</td> <td>46</td> <td>53</td> <td>57</td> <td>65</td> <td>70</td> <td>76</td> <td>88</td> <td>101</td> <td>113</td> <td>126</td> <td>137</td> <td>152</td> </tr> <tr> <td>5/16"</td> <td>lb/h¹</td> <td>254</td> <td>274</td> <td>320</td> <td>345</td> <td>394</td> <td>425</td> <td>462</td> <td>528</td> <td>680</td> <td>756</td> <td>834</td> <td>910</td> <td>1010</td> </tr> <tr> <td>3/8"</td> <td>cfm¹</td> <td>55</td> <td>63</td> <td>76</td> <td>82</td> <td>91</td> <td>100</td> <td>109</td> <td>126</td> <td>143</td> <td>161</td> <td>173</td> <td>196</td> <td>220</td> </tr> <tr> <td>3/8"</td> <td>lb/h¹</td> <td>374</td> <td>428</td> <td>517</td> <td>555</td> <td>620</td> <td>682</td> <td>744</td> <td>860</td> <td>970</td> <td>1080</td> <td>1184</td> <td>1296</td> <td>1454</td> </tr> <tr> <td>7/16"</td> <td>cfm¹</td> <td>72</td> <td>85</td> <td>100</td> <td>112</td> <td>124</td> <td>137</td> <td>149</td> <td>170</td> <td>194</td> <td>217</td> <td>240</td> <td>254</td> <td>300</td> </tr> <tr> <td>7/16"</td> <td>lb/h¹</td> <td>488</td> <td>576</td> <td>678</td> <td>759</td> <td>835</td> <td>840</td> <td>908</td> <td>1160</td> <td>1320</td> <td>1476</td> <td>1630</td> <td>1782</td> <td>2104</td> </tr> <tr> <td>1/2"</td> <td>cfm¹</td> <td>96</td> <td>112</td> <td>129</td> <td>146</td> <td>165</td> <td>179</td> <td>195</td> <td>224</td> <td>252</td> <td>280</td> <td>309</td> <td>338</td> <td>392</td> </tr> <tr> <td>1/2"</td> <td>lb/h¹</td> <td>629</td> <td>734</td> <td>845</td> <td>976</td> <td>1103</td> <td>1197</td> <td>1305</td> <td>1500</td> <td>1700</td> <td>1890</td> <td>2088</td> <td>2277</td> <td>2640</td> </tr> <tr> <td>5/8"</td> <td>cfm¹</td> <td>173</td> <td>195</td> <td>212</td> <td>239</td> <td>260</td> <td>282</td> <td>308</td> <td>356</td> <td>404</td> <td>452</td> <td>504</td> <td>548</td> <td>611</td> </tr> <tr> <td>5/8"</td> <td>lb/h¹</td> <td>1081</td> <td>1219</td> <td>1325</td> <td>1470</td> <td>1600</td> <td>1716</td> <td>1875</td> <td>2140</td> <td>2422</td> <td>2690</td> <td>2973</td> <td>3250</td> <td>3623</td> </tr> </tbody> </table> <p>And use only straight couplings as indicated in the manual</p>	WORKING PRESSURES (psi) ²													Nozzle I.D.	Units	20	25	30	35	40	45	50	60	70	80	90	100 ^a	120	1/8"	cfm ¹	7	7	8	9	10	12	13	14	15	17	19	20	25	1/8"	lb/h ¹	48	48	55	62	69	73	77	82	110	127	140	154	192	3/16"	cfm ¹	15	16	18	20	22	24	26	30	33	38	41	45	55	3/16"	lb/h ¹	94	101	114	127	140	153	166	192	220	243	268	297	363	1/4"	cfm ¹	27	30	34	37	41	45	49	55	61	68	74	81	97	1/4"	lb/h ¹	174	193	219	251	276	303	329	369	398	460	504	556	666	5/16"	cfm ¹	42	46	53	57	65	70	76	88	101	113	126	137	152	5/16"	lb/h ¹	254	274	320	345	394	425	462	528	680	756	834	910	1010	3/8"	cfm ¹	55	63	76	82	91	100	109	126	143	161	173	196	220	3/8"	lb/h ¹	374	428	517	555	620	682	744	860	970	1080	1184	1296	1454	7/16"	cfm ¹	72	85	100	112	124	137	149	170	194	217	240	254	300	7/16"	lb/h ¹	488	576	678	759	835	840	908	1160	1320	1476	1630	1782	2104	1/2"	cfm ¹	96	112	129	146	165	179	195	224	252	280	309	338	392	1/2"	lb/h ¹	629	734	845	976	1103	1197	1305	1500	1700	1890	2088	2277	2640	5/8"	cfm ¹	173	195	212	239	260	282	308	356	404	452	504	548	611	5/8"	lb/h ¹	1081	1219	1325	1470	1600	1716	1875	2140	2422	2690	2973	3250	3623
WORKING PRESSURES (psi) ²																																																																																																																																																																																																																																																																														
Nozzle I.D.	Units	20	25	30	35	40	45	50	60	70	80	90	100 ^a	120																																																																																																																																																																																																																																																																
1/8"	cfm ¹	7	7	8	9	10	12	13	14	15	17	19	20	25																																																																																																																																																																																																																																																																
1/8"	lb/h ¹	48	48	55	62	69	73	77	82	110	127	140	154	192																																																																																																																																																																																																																																																																
3/16"	cfm ¹	15	16	18	20	22	24	26	30	33	38	41	45	55																																																																																																																																																																																																																																																																
3/16"	lb/h ¹	94	101	114	127	140	153	166	192	220	243	268	297	363																																																																																																																																																																																																																																																																
1/4"	cfm ¹	27	30	34	37	41	45	49	55	61	68	74	81	97																																																																																																																																																																																																																																																																
1/4"	lb/h ¹	174	193	219	251	276	303	329	369	398	460	504	556	666																																																																																																																																																																																																																																																																
5/16"	cfm ¹	42	46	53	57	65	70	76	88	101	113	126	137	152																																																																																																																																																																																																																																																																
5/16"	lb/h ¹	254	274	320	345	394	425	462	528	680	756	834	910	1010																																																																																																																																																																																																																																																																
3/8"	cfm ¹	55	63	76	82	91	100	109	126	143	161	173	196	220																																																																																																																																																																																																																																																																
3/8"	lb/h ¹	374	428	517	555	620	682	744	860	970	1080	1184	1296	1454																																																																																																																																																																																																																																																																
7/16"	cfm ¹	72	85	100	112	124	137	149	170	194	217	240	254	300																																																																																																																																																																																																																																																																
7/16"	lb/h ¹	488	576	678	759	835	840	908	1160	1320	1476	1630	1782	2104																																																																																																																																																																																																																																																																
1/2"	cfm ¹	96	112	129	146	165	179	195	224	252	280	309	338	392																																																																																																																																																																																																																																																																
1/2"	lb/h ¹	629	734	845	976	1103	1197	1305	1500	1700	1890	2088	2277	2640																																																																																																																																																																																																																																																																
5/8"	cfm ¹	173	195	212	239	260	282	308	356	404	452	504	548	611																																																																																																																																																																																																																																																																
5/8"	lb/h ¹	1081	1219	1325	1470	1600	1716	1875	2140	2422	2690	2973	3250	3623																																																																																																																																																																																																																																																																
	<p>Underpressure² phenomenon (the vessel pressure is lower than the thrust line pressure)</p> 	<p>Identify the air leak that is escaping from the vessel and preventing it from building its pressure properly</p> <ol style="list-style-type: none"> 1. Plunger 2. Plunger O-Ring 3. Self-depressurization system (if equipped) 4. Access door (if equipped) <p>1st Step - Bubbling method</p> <ul style="list-style-type: none"> • Plunger and/or Plunger O-Ring • Access door <p>2nd Step – Push line cut-off</p> <ul style="list-style-type: none"> • Self-depressurization system 																																																																																																																																																																																																																																																																												


²The underpressure phenomenon exerts a negative pressure upstream of the abrasive flow at the outlet of the pressure vessel. This prevents the abrasive from flowing freely by gravity into the push line.

TROUBLESHOOTING (END)


TYPE OF FAILURE	POSSIBLE CAUSE	SOLUTION
Lack of abrasive in the mix (the nozzle blows mainly air) 	Wrong adjustment of the AR7 abrasive valve 	<ol style="list-style-type: none"> 1. Open the rubber tube opening slightly by turning the crank handle counterclockwise $\frac{1}{4}$" turn at a time 2. Advance the sanding for approximately 20 seconds and note the difference. 3. Repeat steps 1 and 2 as needed 

¹Perform $\frac{1}{4}$ " of a turn at a time and observe the difference. It takes about 30 seconds for the system to renew the air/media mix in the line.

SCHEMATIC OF UNIT - EXPLODED VIEW & PARTS





1	603212	Gloves with nylon sleeves e3 8" i.d. x 30" length
	603205	gloves with leather sleeves e3 8" i.d. x 30" length
1A	603217	wide opening gloves nylon sleeves w1 10" i.d. x 30" length
1B	603218	wide opening gloves leather sleeves w1 10" i.d. x 30" length
2	624128	8" ø glove "t" clamp (standard)
2A	624137	10" ø glove "t" clamp (optional) 30, 31
3		hose, couplings and nozzles (see page 13)
4	610288	standard door handle
5	610275	dust blow-off gun
6	608022	½" pressure regulator 41
7		complete foot pedal-press ²⁹ (see page 29)
8		complete recycler (see page 16)
9	606120	reclaimer hose 5" – 600 cfm
10	606123	reclaimer hose 6⅛" – 900 to 1800 cfm
11	624121	5" clamp
12	624124	6" clamp
13	618131	rubber grommet for abrasive hose ½"
14	940025	Star knob
15	666214	pressure manifold (see page 32)
16	324571	¼" Poly. blue tubing air hose (sold by foot)
17	611022	¼" Pressure Gauge
18*	616933	AGC fuse 1A - 250 V
19*	616907	fuse holder
20	617014	ON/OFF switch
21	617161	24" light fixture c/w led
22	617160	48" light fixture c/w led
23	610212	23¾" x 18¾" laminated safety glass (cabinet less than 48")
24	610211	17" x 48" laminated safety glass (cabinet 48" and more)
	618318	Window seal type "G15"(sold by foot)
20	613038	rpw 50 – 23 ¾" x 18 ¾" acetate glass protector
21	613035	rpw 1748 acetate glass protector (cabinet 48" and more)
22	910223	Door toggle Stem
23	618322	door rubber gasket type "P"
	610453	28" x 44"
	610458	36" x 36"
	610459	36" x 48"
23	610462	42" x 48"
	610463	48" x 48"
	610469	48" x 60"
	610465	60" x 60"
24	600116	Complete Door Safety Switch



Standard :
Round opening gloves

Optionnal :
Wide opening gloves



RECYCLING SYSTEM - EXPLODED VIEW & PARTS LIST

10" RECYCLING SYSTEM		
NB	PART NB	DESCRIPTION
1	609256	10" HOPPER
2	618318	SELF-ADHESIVE RUBBER
3	618334	RUBBER BAND
4	609225	RECYCLER BODY
5	609313	RECYCLER BODY BRACKET
6	606161	ABRASIVE HOSE CONVEYOR
7	609216	10" VERTICAL OUTLET BOX
8	See p.34	ABRASIVE DUST CONVEYOR

SANDBLASTING CABINETS - HOSES, COUPLINGS & NOZZLES

HOSE, COUPLINGS & NOZZLES

1	607012	1/2" CQ Coupling
2	607020	1/2" SBH SANDBLAST HOSE
3	607059	NC3-N3 1/2" x 1" NPT
CONICAL NOZZLE		
5	607040	NA-1" Adaptor 1" NPT
6	607057	NH-1/2" Adaptor 3/4" NPS
7	607056	NH-1/2" Adaptor 1 1/4" NPS
STRAIGHT THREADED NOZZLE 3/4" NPS		
9	DOUBLE VENTURI NOZZLE 1 1/4" NPS or 50mm	

BULK SANDBLAST HOSES (LENGTH OF 12.5', 25' & 50' ONLY)

PART NB.	MODEL	INSIDE DIAMETER	OUTSIDE DIAMETER
606020	SBH-1/2	1/2"	1 3/16"

HOSES FITTINGS

PART NB.	MODEL	INSIDE DIAMETER	OUTSIDE DIAMETER
607002	QC-1/2	1/2"	1 3/16"

THREADED NOZZLE FITTINGS

MODEL	HOSE I.D.	THREAD		
		3/4" NPS	1 1/4" NPS	50 mm
607057	1/2"	607057	607056	* 407022

SANDBLASTING CABINETS - HOSES, COUPLINGS & NOZZLES (CONT'D)**CONICAL NOZZLE**

#	TYPE	PART NO	MODEL	ORIFICE	LENGTH	THREAD
(4)	DC2-F - TUNGSTEN CARBIDE	605302	DC2-F2	1/8" Ø	1-5/8"	N/A
		605303	DC2-F3	3/16" Ø		
		605304	DC2-F4	1/4" Ø		
	BN2-F - BORON CARBIDE	605308	BN2-F2	1/8" Ø		
		605309	BN2-F3	3/16" Ø		
		605310	BN2-F4	1/4" Ø		

STRAIGHT THREADED NOZZLE

(8)	DC1 - TUNGSTEN CARBIDE	605358	DC1-2	1/8" Ø	3/4" - 1/4" N.P.S.	1-3/4"
		605359	DC1-3	3/16" Ø		
		605360	DC1-4	1/4" Ø		
		605361	DC1-5	5/16" Ø		
	BC1 - BORON CARBIDE	605414	BC1-2	1/8" Ø		
		605415	BC1-3	3/16" Ø		
		605416	BC1-4	1/4" Ø		
		605417	BC1-5	5/16" Ø		

DOUBLE VENTURI NOZZLE

(9)	DOUBLE VENTURI NOZZLE	405463	# 3	3/16" Ø	4 1/16"	50 mm
		405464	# 4	1/4" Ø	5 5/16"	
		405465	# 5	5/16" Ø	6 1/16"	
		405466	# 6	3/8" Ø	6 1/8"	
		405467	# 7	7/16" Ø	8 15/32"	
		405468	# 8	1/2" Ø	9 1/16"	

TUNGSTEN CARBIDE

Part Nb	Model	Orifice	Lenght	
605203	DCV-3	3/16" Ø	4 1/4"	Threaded nozzle 1 1/4" N.P.S., 1" Ø entry venturi orifice, use with NCV, all NH- except NH - 1/2"
605204	DCV-4	1/4" Ø	5 1/4"	
605205	DCV-5	5/16" Ø	6"	
605206	DCV-6	3/8" Ø	6 3/4"	
605207	DCV-7	7/16" Ø	8"	
605208	DCV-8	1/2" Ø	9 1/4"	


BORON CARBIDE

Part Nb	Model	Orifice	Lenght	
605454	BCV-4	1/4" Ø	4 1/8"	Threaded nozzle 1 1/4" N.P.S., 1" Ø entry venturi orifice, use with NCV, all NH- except NH - 1/2"
605455	BCV-5	5/16" Ø	4 1/8"	
605456	BCV-6	3/8" Ø	4 1/8"	



TUNGSTEN CARBIDE

Part Nb	Model	Orifice	Lenght	
605313	DC3-3	3/16" Ø	3"	Threaded nozzle 1 1/4" - 14 N.P.S., straight orifice, use with NCV, all NH- except NH - 1/2"
605314	DC3-4	1/4" Ø	3"	
605315	DC3-5	5/16" Ø	3"	
605316	DC3-6	3/8" Ø	3"	


AIR PRESSURE MANIFOLD - STANDARD 1/2" PIPING




#	Part #	DESCRIPTION	#	Part #	DESCRIPTION
1	630301	1/2" MPT Nipple	11	324503	1/4" MTP x 1/4" TU Bulkhead Push-in
2	632745	1/2" MPT x 1/4" FPT Reducer	12	608519	1/2" Pilot Valve (see details p. 13)
3	632270	1/4" FPT x 1/4" Hose Fitting	13	608287	1/2" MPT Muffler
4	630328	MF 1/2" FPT "T"	14	632002	1/8" Hex. Nipple
5	632760	1/2" MPT x 1/2" Hose Fitting	15	632018	1/8" PL T-Street
5A	632730	1/2" PL MF Elbow Fitting	16	324561	1/8" NPT 1/4" TU @ 90° Push-in Fitting
6	932108	1/2" MPT x 3" Lg. Nipple	17	630327	1/2" Cross
7	630340	1/2" FF PA Elbow	18	632226	1/4" T-Street
8	324560	1/4" NPT 1/4" TU @ 90° Push-in Fiting	19	324571	1/4" Blue Poly. Tube
9	610390	1/2" Inlet Ring	20	324558	1/4" MTP 1/4" TU Push-in Fitting
10	608102	1/2" FPT Ball Valve	21	606104	1/2" Clear Nylon Hose

AIR PRESSURE MANIFOLD - STANDARD 1/2" PIPING WITH PLASTIC MEDIA OPTION

1	632214	1/8 TO 1/4" ADAPTOR
2	608608	1/4" REGULATION VALVE
3	314048	1/4" NPT X 1/4" TU 90° PUSH-IN FITTING
4	324571	1/4" BLUE TUBING


AIR PRESSURE MANIFOLD - OPTIONAL 1" PIPING

#	Part #	DESCRIPTION	#	Part #	DESCRIPTION
1	610387	1" Inlet Ring	10	630630	1" PA T-Street
2	630601	1" Nipple	11	608204	1" Check-Valve
3	608104	1" Ball Valve	12	632270	1/4" NPT x 1/4" Hose Barb Fitting
4	630629	1" Cross Fitting	13	324560	1/4" NPT 1/4" TU @ 90° Push-in Fitting
5	630653	1" x 1/4" Reducer	14	632002	1/8" Hex. Nipple
6	632232	1/4" F x 1/4" M Elbow Fitting	15	324561	1/8" NPT 1/4" TU @ 90° Push-in Fitting
7	630605	1" x 3" Lg. Nipple	16	632018	1/8" PL Brass T
8	608069	1" WATTS Valve (Complete Ass'y)	17	606104	1" x 1/2" Reducer
8A	608064	Kit : Assembl. Diaphragm H. & B. - Ass. disc (Pop Pet) O-Ring, Valve Plug.	18	630690	1" Hose Barb Fitting
8B	608066	1" - 1 1/4" WATTS Valve Plug	19	630641	1" Elbow Fitting
8C	608071	Recall Spring	20	324558	1/4" MTP 1/4" TU Push-in Fitting
9	632226	1/4" T-Street	21	324571	1/4" Blue Poly. Tube
			22	324503	1/4" MTP x 1/4" TU Bulkhead Push-in
			23	606104	1/2" Clear Nylon Hose


PRESSURE VESSEL - EXPLODED VIEW & PARTS

#	STOCK	DESCRIPTION
1	618205	M101P "O" RING
2	610040	M101P PLUNGER
3	610313	M101P PRESSURE VESSEL
4	611022	1/4" PRESSURE GAUGE
5	608102	1/2" BALL VALVE
	608104	1" BALL VALVE (OPTIONAL)

#	STOCK	DESCRIPTION
6	606001	1/2" SBH HOSE (SOLD PER FOOT)
	606005	1" SBH HOSE OPTIONAL (SOLD PER FOOT)
7	610311	2" SIGHT GLASS (OPTIONAL)
8	630671	1" PA MALE PLUG


OPTION : ROTARY TABLE ON RAILS

#	STOCK	DESCRIPTION
23	619121	18"
	619122	21"
	619123	28"
	619124	32"
	619125	36"
	619126	40"
	619127	48"
24	619022	4" WHEEL WITH «V» GROOVE C/W BUSHING
24A	619025	BUSHING ONLY (FOR WHEEL)
25	619023	1" AXLE BEARING
26	940024	1/4" LINATEX RUBBER COVERAGE


OPTION : DOOR SAFETY SWITCH - INSTALLATION KIT (600116)

1. Place the door safety switch **1** as shown and drill 2 holes 5/32" and secure with 2 screws + nuts and washers **2** (supplied)
2. Place the screw plate screw in front of the switch button, mark and drill 2 holes 7/32 " in the door, and screw the 2 screws + cap nuts **3** (supplied)
3. Push the poly. blue tubes **4** in push-in **5** and **6** (supplied), attach them with a Ty-Rap **7** and its self-adhesive support **8** (supplied).


ID	PART NB	DESCRIPTION
1	908501	THREE WAYS AIR VALVE 1/8" PORT
2	NPN	2 SETS OF SCREW AND NUT & WASHER (SUPPLIED)
3	NPN	2 SETS OF SCREW + WASHER & DOME NUT (SUPPLIED)
4	324571	15' OF BLUE POLY. TUBE 1/4"
5	324561	90° PUSH IN FITTING 1/8"" NPT 1/4" TUBE
6	324570	STRAIGHT PUSH IN 1/4 X 1/8"
7	616706	NYLON TY-RAP 3 1/2"
8	616717	TY-RAP MOUNTING (1x2)

OPTION : VERTICAL DOOR WITH MANUAL COMMAND


#	STOCK	DESCRIPTION
1	324571	1/4" BLUE POLY. TUBING
2	908699	1/4" NPT FLOW CONTROL
3	324560	1/4" @ 90° PUSH IN FITTING
4	908589	MANUAL VALVE « OPEN/CLOSED »
5, 6	908820	CYLINDER 39" STROKE
7	NPN	CYLINDER MOUNTING PLATE
8	908659	FLOW CONTROL WITH CHECK VALVE
9	908501	VERTICAL DOOR SWITCH (OPTION.)

AR7 REGULATOR & DEPRESSURIZING SYSTEM - VIEWS & PARTS**AR7 ABRASIVE REGULATOR**

A	STOCK	DESCRIPTION
1	608093	HANDLE
2	608091	RETAINING PLATE
3	608039	REGULATION FLOW SCREW
4	608096	CLAMPING BOLTS (SOLD BY KIT)
5	608047	LOWER HOUSING
6	608037	CRUSHING STRIER
7	608040	REGULATION PLATE
8	608036	REGULATION TUBE
9	618228	RUBBER TUBE
10	618231	GASKET SEAL

DEPRESSURIZING SYSTEM


#	STOCK	DESCRIPTION
1	324560	1/4" @ 90° Push-in Coupling
2	630860	1 1/4" x 1" Bushing (incl. W. #15)
3	630624	1" ced. 80 PA Nipple
4	605011	BN2-5 5/16 Nozzle
5	618110	G5 O-Ring
6	630690	1" Adaptor
7	607087	1 1/4" Hose Clamp double bolt
8	606005	SBH 1" Sandblast Hose (sold per ft.)
9	630605	1" x 7" lg. PA Nipple
10	630671	1" M Plug
11	630630	1" PA Tee
12	630680	1" PA Union
13	610070	Depress Spacer
14	608104	1" Ball Valve
15	608611	1" NPT depress. valve
	608612	Diaphragm only (for 608611)
16	630605	1" x 3" lg. PA Nipple

DCM100 TO 330 BAGHOUSE SERIES DUST COLLECTOR

#	PART #	DESCRIPTION
1		Hoses : see table page 35
2		Clips : see table page 35
3		Fan Motor : see table page 35
4	608508	Pneumatic Shacker Button
5	608408	Flow Adjust 10-32 Slotted
6	632064	1/8" 10-32 MPT Hose Barb Fitting
7	608409	1/4" Reducer pour Flow Adjust
8	-/->	Air Inlet (1/4" M # 607222, & 1/4" F # 607219 Quick Connect)
9	608406	Clevis Rod
10	619005	2" Roller
11	608405	3/4" Ø x 3" stroke Cylinder
12	608407	Bracket for cylinder
13	610280	8" Adjustable Air Inlet
14	610287	Complete Door Handle

#	PART #	DESCRIPTION
15	910223	Door Toggle Stem
16	601378	Dust Trap
17	618321	"D" Type Rubber Seal (sold by foot)
18	616575	Electric Cable (sold by foot)
19	616406	Electric Plug
20	617063	Electric Box
21	601309	"S" Hook
22	609158	4" Dust Hose (sold by foot)
23		Dust Bags (see table page 35)
24		Option : Barrel & Extension Legs (see page 35)
25		Option : Horizontal Muffler (see page 35)
26		Option : Vertical Muffler (see page 35)
27		Trolley for Barrel

DCM 600 TO 1800 CARTRIDGE DUST COLLECTOR SERIE - EXPLODED VIEW & PARTS



#	PART #	DESCRIPTION
1		Hoses : see table page 35
2		Clamps : see table page 35
3		Motor : see table page 35
4	611058	1/8" Inline Filter
5	632248	1/4" @ 1/8" HEX. Reducer
6	NPN	Cartridge Guide
7		Filtering Cartridge : see table p. 35
8	NPN	Access Door
9	940109	Star Knob
10	NPN	Cartridge Lock Key
11	630651	1" @ 1/2" Reducer
12	608022	1/2" Complete Pressure Regulator

#	PART #	DESCRIPTION
13	608102	1/2" Ball Valve
14	607222	1/4"-1/4" NPT Quick-Connect Fitting
14A	630351	1/2" @ 1/4" MF Reducer
15	630641	1" MF @ 90° Elbow
16	901448	30 gal Collecting Barrel
17	618321	« D » Type Rubber Seal (Sold by foot)
18	324560	1/4" NPT @ 1/4" TU Push-in Fitting
19	932004	1/4" FF Bulkhead Fitting
20	919325	Trolley for Barrel
21	630125	1/4" MF @ 90° Elbow
22	630141	1/4" @ 1/8" Reducer


DUST COLLECTORS : MOTORS, HOSES AND BAGS OR CARTRIDGES

FAN MOTOR & SUCTION HOSE



BARBED SUCTION HOSES AND CLAMPS


Fan Motor (hp)	Hose I.D.	Hose (1)	Clamp (2)
1/2	5"	606168	624121
1	6"	606169	624124
2	7"	606171	624127
3	8"	606173	624128
5	10"	606177	624137



FAN MOTOR

Power (hp) ①	Voltages		Fan ②
	240 V	380 V	
1/2	IST	S/O	610525
1	IST	S/O	610526
2	IST	S/O	610527
3	S/O	IST	610528
5	S/O	IST	610529
7.5	S/O	IST	IST
10	S/O	IST	IST

#	PART #	DUST BAGS
23	601316	DC 100 : DB6HP Dust Bags (Qty : 16)
		DC 160 : DB6HP Dust Bags (Qty : 25)
		DC 230 : DB6HP Dust Bags (Qty : 36)
	601308	DC 330 : DB9HP Dust Bags (Qty : 36)



FILTERING CARTRIDGES


#	PART #	MODEL	QTY
7	901321	DCM600	2
		DCM900	
		DCM1200	4
		DCM1800	

BAGHOUSE DUST COLLECTOR OPTIONS

DCM MODEL	OPTION Nb.	BARREL CAPACITY (gal)	OPTION DUST BARREL & LEGS ②4	HORIZONTAL MUFFLER ②5	VERTICAL MUFFLER ②6
			②5		
*DCM-100-4	601486	15		601434	601423
DCM-100	601486	15		601434	601423
DCM-160	601487	30		601435	601424
DCM-230	601490	30		601436	601425
DCM-330	601490	30		601437	601426



* For ECAB pressure cabinet only.

STANDARD FOOT PEDAL - PARTS DETAIL




#	STOCK	DESCRIPTION
1	908065	Pneumatic Foot Pedal (complete)
2	950264	1/4" Push-in Fittings
3	632551	1/4" Brass Plug

NO-CONTACT FOOT PEDAL (OPTIONAL) PEDAL & PARTS



#	STOCK	DESCRIPTION
1	608568	SOLENOID VALVE
2	324561	1/8" PUSH-IN FITTING
3	632214	ADAPTER 1/8" TO 1/4"
4	632745	ADAPTER 1/2" TO 1/4"
5	910525	COMPLETE NO-CONTACT FOOT PEDAL
6	917879	INFRARED SENSOR CELL

CONTROL PANEL WITH PARTS




#	STOCK	DESCRIPTION
1	917618	24V DC - POWER SUPPLY 30W - 120/24
2	917877	24V DC RELAY
3A	917893	MDL.2A FUSE
3B	616933	AGC-1A FUSE
4	-/-	TERMINAL BLOCKS
5	616865	GROUND BLOCKS
6	917880	SENSOR CABLE

RECOMMENDED SPARE PARTS


Description	Configuration	Part No	Qty
Cabinet			
Leather Gloves	All Models	603205	1
Nozzle 5/16" ID*		405465	
'Blast Hose (sold by foot)'	2636-2844-3636-3648-4248-4848	606020	7
	3660-3672-4860-4872-6060-6072		12
Safety Glass	2636-2844-3636-3648-4248-4848	610212	1
	3660-3672-4860-4872-6060-6072	610211	5
Window Shield	2636-2844-3636-3648-4248-4848	613038	1
	3660-3672-4860-4872-6060-6072	613035	5
Reclaiming Hose	DCM100-DCM600	606120	8
	DCM100-DCM600	606123	
	DCM230-DCM1200	606124	
Dust Collector			
Filtering Bag	DCM100	601316	16
	DCM160		25
	DCM230		36
Filtering Cartridge	DCM600	901321	2
	DCM900		4
	DCM1200		4
Dust Carrying Hose	DCM100-DCM600	606169	12
	DCM160-DCM900	606171	
	DCM230-DCM1200	606173	
Pressure Vessel			
AR7 Rubber Tube	All Models	618228	1
O-RING		618205	
Plunger		610040	
Nozzle 5/16" ID		605011	
Cap		630671	2
Depressurization Valve		608611	1
Diaphragm		608612	

*Corresponds to the standard items and may not reflect your actual cabinet configuration

PNEUMATIC DIAGRAM




ELECTRICAL SCHEMATIC WITH DCM 50 TO 330 BAG-TYPE - 1 PH - DRAWING




ELECTRICAL SCHEMATIC WITH DCM 50 TO 330 BAG-TYPE - 1 PH - PARTS LIST

ELECTRICAL SCHEMATIC WITH DCM 50 TO 330 BAG-TYPE - 3 PH - DRAWING




ELECTRICAL SCHEMATIC WITH DCM 50 TO 330 BAG-TYPE - 3 PH - PARTS LIST

ELECTRICAL SCHEMATIC WITH DCM 600 TO 1800 CARTRIDGE TYPE - 1 PH - DRAWING

ELECTRICAL SCHEMATIC WITH DCM 600 TO 1800 CARTRIDGE TYPE - 1 PH - PARTS LIST

ELECTRICAL SCHEMATIC WITH 600 TO 1800 CARTRIDGE TYPE - 3 PH - DRAWING



ELECTRICAL SCHEMATIC WITH 600 TO 1800 CARTRIDGE TYPE - 3 PH - PARTS LIST

REFERENCE LIST FOR M-SERIE DCM 50 TO 330 & 600 TO 1800

MOTOR RATINGS VOLTS INPUT, STARTER AND OVERLOAD SELECTION											
	POWER	VOLTS	AMPS	PHASES	HERTZ	RPM	STARTER	OVERLOAD	CUSTOMER FUSE TYPE AND CAPACITY		
302	2HP	208-230/460V	6-5.4/2.7A	3	60	3450	LEID093A620G70	LRD121LRD08	AJT8-AJT7/AJT4		
303	2HP	575V	2.16A	3	60	3450	LEID093A620G70	LRD010LRD07	AJT3		
304	3HP	208-230/460V	8.1-7.3/3.6A	3	60	3450	LEID093A620G70	LRD141LRD08	AJT12-AJT10-AJT5		
305	3HP	575V	2.9A	3	60	3450	LEID093A620G70	LRD141LRD08	AJT4		
306	5HP	208-230/460V	13.3-12/6.1A	3	60	3450	LCID18671LCD12G7	LRD211LRD12	AJT20-AJT15/AJT8		
307	5HP	575V	4.8A	3	60	3450	LCID18671LCD12G7	LRD211LRD10	AJT6		
308	7.5HP	575V	7.1A	3	60	3450	LEID093A620G70	LRD12	AJT9		
309	7.5HP	460V	8.8A	3	60	3450	LEID093A620G70	LRD14	AJT12		
310	10HP	460V	12A	3	60	3450	LCID12G7	LRD16L	AJT16		
311	10HP	575V	9.3A	3	60	3450	LCID12G7	LRD14	AJT12		
312	CONTROL TRANSFORMER SELECTION										
PRIMARY VOLTAGE	VA	PHASES		SECONDARY VOLTAGE			PART NO	PRIMARY FUSE			
600VAC	50		1	60	120VAC		SC-LA9TFD32X	0.2 amp			
480VAC	50		1	60	120VAC		SC-LA9TFD32T	0.2 amp			
240VAC	50		1	60	120VAC		SC-LA9TFD32M	0.6 amp			
313	MOTOR RATINGS VOLTS INPUT AND SELECTION										
POWER	VOLTS	AMPS	PHASES	HERTZ		RPM	PARTS NO	MAKER			
2HP	208-230/460V	6-5.4/2.7A	3	60		3450	YSN564G2A2X4	JRP			
2HP	575V	2.16A	3	60		3450	YSN564G5/5	JRP			
3HP	208-230/460V	8.1-7.3/3.6A	3	60		3450	NEP1821TC2-2X4	NORDIC			
3HP	575V	2.9A	3	60		3450	NEP1821TC2C-5	NORDIC			
5HP	208-230/460V	13.3-12/6.1A	3	60		3450	NEP184TC2-2X4	NORDIC			
5HP	575V	4.8A	3	60		3450	NEP1821TC2-5	NORDIC			
7.5HP	575V	7.1A	3	60		3450	NEP2131TC2-5	NORDIC			
7.5HP	460V	8.8A	3	60		3450	NEP2131TC2-2X4	NORDIC			
10HP	460V	12A	3	60		3450	NEP2151TC2-2X4	NORDIC			
10HP	575V	9.3A	3	60		3450	NEP2151TC2-5	NORDIC			
314	EXCLUSIVE RIGHTS, PROPRIÉTÉ EXCLUSIVE DE IST SURFACE INC. TOUTE FORMATION CONCERNANT LA TECHNOLOGIE ET LE LOGICIEL QUI PEUT ÊTRE UTILISÉ OU ACCÈS À LA TECHNOLOGIE ET LE LOGICIEL DE IST SURFACE INC. EST SOUS RESERVE DE RESTER LA PROPRIÉTÉ EXCLUSIVE DE IST SURFACE INC. SI UN UTILISATEUR ACCÈSE À LA TECHNOLOGIE ET LE LOGICIEL DE IST SURFACE INC. EN VERTU D'UN CONTRAT DE CONFIDENTIALITÉ, IL NE PEUT PAS FAIRE DES TRANSMISSIONS À TOUTE AUTRE ORGANISATION.										
315	M SERIE DCM 600 - 2000 3PH POWER & CONTROL REFERENCE LIST										
316	DROITS SEULS AU FABRICANT PRODIGEUS SUR LA TECHNOLOGIE ET LE LOGICIEL QUI PEUT ÊTRE ACCÈS À LA TECHNOLOGIE ET LE LOGICIEL DE IST SURFACE INC. TOUTE FORMATION CONCERNANT LA TECHNOLOGIE ET LE LOGICIEL QUI PEUT ÊTRE UTILISÉ OU ACCÈS À LA TECHNOLOGIE ET LE LOGICIEL DE IST SURFACE INC. EST SOUS RESERVE DE RESTER LA PROPRIÉTÉ EXCLUSIVE DE IST SURFACE INC. SI UN UTILISATEUR ACCÈSE À LA TECHNOLOGIE ET LE LOGICIEL DE IST SURFACE INC. EN VERTU D'UN CONTRAT DE CONFIDENTIALITÉ, IL NE PEUT PAS FAIRE DES TRANSMISSIONS À TOUTE AUTRE ORGANISATION.										
317	LAURENT GOLDSCHMITT Customer: IST SURFACE										
318	Drawing Number: IST-202C Date: 2019-11-06										
319	Rev. Date: 2021-12-03 08:56:11 Page: 3 / 4										
320	ISTblast 1050 Des Forges Street Hwy 640 Industrial Park Tel 1 877 625 8202 • 450 953 4400 • fax 450 953-										

IST LIMITED WARRANTY

IST warrants all equipment led in this manual which is manufactured by **IST** and bearing its name, to be free from defects in material and workmanship on the date of sale by an authorized **IST** distributor to the original purchaser for use. Notwithstanding any special, extended or limited warranty published by **IST** will, for a period of TWENTY FOUR (24) months from the date of sale, repair or replace any part of the equipment determined by **IST** to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with **IST**'s written recommendations.

This warranty does not cover, and **IST** shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-**IST** component parts. Nor shall **IST** be liable for malfunction, damage or wear caused by the incompatibility with **IST** equipment with structures, accessories, equipment or materials not supplied by **IST**, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by **IST**.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized **IST** distributor for verification of the claimed defect. If the claimed defect is verified, **IST** will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser, transportation prepaid. If the inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

IST's sole obligation and the buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought forward within one (2) years of the date of sale.

IST MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY **IST.** These items sold, but not manufactured by **IST** (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. **IST** will provide the purchaser with reasonable assistance in making any claim for breach of these warranties.

LIMITATION OF LIABILITY

In no event will **IST** be liable for indirect, incidental, special or consequential damages resulting from **IST** supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of **IST**, or otherwise.

Report all accidents or "near misses" which involve **IST products to:**

- **Technical Assistance**

The following items are not covered under the **IST warranty policy:**

- Parts or chassis replacement due to normal wears.

Defective material or workmanship is not considered normal wear

1ST WARRANTY REGISTRATION

IST would like to thank you for your recent purchase of our product line. Please complete the card below and either mail or fax it to our office so that we may start the warranty of your product and keep you up to date on the EPA regulations by fax. Again, thank you for your purchase and if you have any suggestions or comments, please feel free to contact our office.

COMPANY NAME : _____

ADDRESS : _____

CITY: _____ **STATE/PROV.:** _____

CONTACT: [REDACTED]

FAX NUMBER: | | | | | | | - | | | | | |

DATE OF PURCHASE: | | | | | | | | | |

Month Day Year

TYPE OF MEDIA USED: _____

Which factors most influenced your decision to purchase this unit?

SUGGESTIONS ABOUT THE EQUIPMENT:

Please fill out the form above and send it to us by mail, email or fax so we can register your product and keep you updated on the latest regulations released by the EPA. We thank you for your purchase and remain at your entire disposal for any further query regarding the operation of your equipment.

International Surface Technologies

**1050 Des Forges Street
Hwy. 640 Industrial Park
Terrebonne, Quebec
J6Y 0P6 Canada**

Phone : (877) 629-8202
General Email : info@jtsurface.co

ABOUT THE COMPANY

WHO WE ARE

IST is a leading manufacturer of equipment for the surface treatment industry and the solvent recycling industry. Our extensive line of equipment includes batch units and automated machines designed to achieve the highest manufacturing standards.

MISSION

IST works tightly with their customers to transform industrial processes to improve their quality, productivity, and environmental footprint.

OUR SERVICES

- Custom Design & Fabrication
- Installation & Startup
- Preventative Maintenance Program
- Private Labels
- Testing Lab
- 24/7 Technical Support 5656

INDUSTRIES WE SERVE

- Aerospace & Aviation
- Aluminium Smelters
- Automotive
- Construction & Civil Engineering
- Flexography (labelling) & Lithography
- Foundry & Forge
- General Manufacturing
- Military
- Power & Energy
- Rail & Mass Transit
- Shipyards
- Wood finishing

