



# **GWM 300**



# **ACCESSORIES INCLUDED**

- ✓ Adapter tubes and fitters
- Exhaust for solvent fume extraction
- "Blue Filter" kit
- Instruction Manual



- Warranty Safety

- Operation
- Service Parts
- Accessory Information Registration Form

Part # 350300

**(€ (Ex)** II 2G T6





# **TABLE OF CONTENTS**

Pag	ge
ETTING THE MACHINE UP3	3
MAINTENANCE SCHEDULE3	3
NSTALLATION OF CONTAINERS4	4
XHAUST INSTALLATION - DAILY OPERATION & MAINTENANCE5	5
PERATING THE CLEANER6	5
PERATING THE CLEANER (CONT'D)7	7
PTIONAL BLUE FILTER8	3
ECOMMENDATIONS9	9
ECHNICAL SPECIFICATIONS & AIR PIPING10	0
XPLODED VIEW & PARTS LIST1	1
STPURE LIMITED WARRANTY	2
VARRANTY REGISTRATION1	3
NFORMATION / TECHNICAL ASSISTANCE14	4
OUR MAP LOCATION15	5
DUR MISSION	6





### **SETTING THE MACHINE UP**

### **PLEASE NOTE**

We advise using an air, dirt and water trap filter at the air inlet at the cleaner. This will protect the valves and cylinder from dirt and water contamination.

It is possible to obtain 100/150 gun washes from a 5 gal drum of solvent but results may vary upon how much paint material is left in your spray gun cup. We recommend regular changing of the solvent to ensure absolute cleanliness of your spray gun.

- Position machine in a well ventilated area. The extraction outlet will accept 3" hose and should be connected to an existing system or taken to the external part of a building and vented via the atmosphere.
- Connect the machine to the air supply. All air connections are located on the right hand side of the machine when viewed from the front.
- Connect earth wire on rear of machine to suitable earthing point.

Air Supply Pressure: 76 to 100 psi. Thread size: 1/4" NPT

#### **MAINTENANCE SCHEDULE**

Frequence	DAILY OPERATION & MAINTENANCE	
Action	<ul> <li>Clean the suction filter every time you replace the solvent drums.</li> <li>Check the dirt and water trap and empty when necessary.</li> <li>DO NOT ALLOW THIS TO FILL AND BLOCK</li> </ul>	

Frequence	EVERY MONTH
Action	<ul> <li>Add two drops of air tool oil into the air side of the two pumps inside the machine.</li> </ul>

Frequence	EVERY 6 MONTHS	
Action	<ul> <li>Change the blue filter cartridge (inline filter) and O-Ring gasket or sooner depending on contamination.</li> </ul>	






### **INSTALLATION OF CONTAINERS**

# **WARNING**<u>DO NOT SMOKE OR USE OPEN FLAME NEAR CABINET.</u>

In order to use the clean rinse feature, you will need one 5 gal drum and one 1.3 gal empty container.




- 1. Fill a 5 gal drum with clean solvent or water, For waterborne cleaning, add 1 x 3.4 oz bottle of water-based cleaner in the drum
- 2. Transfer 1.3 gal of cleaning fluid from the drum into the 1.3 gal container [1]



3. Locate the drain valve lever under the machine and turn lever to vertical position [2]

- 4. Insert hose with suction filter into the 5 gal drum and enter drain tube [3-4].
- 5. Push the 5 gal drum under machine aligning filler neck with bottom part of flexible hose [3-4].
- 6. Place the full 1.3 gal container under the centre of the machine next to the 5 gal drum and insert the black ¼" nylon tube [3-4].
- 7. For solvent-based cleaning, installation of ground wire is required. Connect ground wires equipped with crocodile clamp located inside the machine to any metal solvent containers if used. The machine must also be grounded on a metal structure using the green ground wire located at the back as shown on the picture below [4].







# **EXHAUST INSTALLATION**

#### **AIR EXHAUST INSTALLATION**



Evacuate fume outside of the building or link the exhaust to the building air evacuation system using a 3" flexible aluminum duct.

No additional ventilation system required.

#### **AIR INLET CONNECTION**



We strongly recommend using a dirt / water trap and an air pressure regulator when using your GWM 300.  $\,$ 

The pressure regulator and filter should be installed on the compressed air inlet of the cleaner as shown in the picture.

The air pressure should be set between 76 and 100 psi.





# **OPERATING THE CLEANER**

### **PLEASE NOTE**

For best results spray guns should be cleaned as soon as possible after use.





Turn AIR VALVE to ON when using the washer. This activates the ventilation fume extraction air jet to ensure the operator is not exposed to solvent fumes.

For the most efficient clean, ensure the spray gun and cup are emptied from any residual paint prior to use the GWM 300 cleaner. We recommend to keep a waste paint drum beside the machine to reclaim waste paint.

- 1. Empty the paint cup and remove it from the spray gun (A).
- 2. Remove the air cap and disassemble small parts from the spray gun (B).
- 3. Blow air through the spray gun to remove any residual paint inside (C).











# **OPERATING THE CLEANER (CONT'D)**

#### **MANUAL WASH**

1. Turn ON the MANUAL WASH valve to feed the washer with fluid. CLEAN RINSE valve should be set to OFF [D].



- 2. To use single square nozzles, turn the selection valve along the hose (0 degree) [E].
- 3. To use only the manual flow-through brush, turn the selection valve 90 degrees [F].
- 4. Clean inside of the spray gun using the lower nozzle [G]
- 5. Clean the spray gun surface and the paint cup using manual flow-through brush [H].









#### **CLEAN RINSE**

- 6. Turn ON CLEAN RINSE valve and OFF MANUAL WASH valve [I]. This interrupts supply from main container and enables supply from clean fluid container.
- 7. Rinse inside of the spray gun using the upper nozzle. [J]





#### **DRYING**

8. Blow air inside and outside of the spray gun using the air blow gun on the side of the washer to dry liquid residues [K].








# **BLUE FILTER**

#### **« BLUE FILTER » FILTRATION SYSTEM**



The **inline filtration system "Blue Filter"** enhances the cleaning performance of the washer, increases its life span, lower its maintenance, and reduces wastes by filtering out paint solids from washing fluid.

#### REPLACEMENT OF THE "BLUE FILTER" CARTRIDGE



- Take the cartridge key (1) and gently unscrew the blue cap off the filter.
- Remove the old cartridge and place a new one (2) it into the blue cap (3).
- Ensure the O-ring seal (4) is properly in place and screw the blue cap on the thread and screw it firmly in place using the cartridge key.
- The cartridge (3) must be in place as shown on the picture B.






# **HEALTH AND SAFETY DATA SHEET (HSDS)**

PRODUCT NAME USES	REMOVAL OF PAINT FROM PAINT SPRAY GUNS, CUPS AND HOSES.
GENERAL PRECAUTIONS	Before operating this spray gun washer, operators must be familiar with the correct operating procedures as detailed in the manufacturer's Instruction Manual.  Do not tamper with the safety lid switch, which prevents the unit operating in the cleaning mode when the lid is open.  Close drain valve and close lid when the unit is not in use. All solvent should be drained from the cleaning tank before closing the drain valve.  Inspect solvent storage compartment daily to ensure there is no leaks from the solvent containers.  Replace solvent filter pad frequently (bimonthly replacement of the filter pad is recommended)  Always disconnect the air source before performing maintenance tasks.
FIRE HAZARDS	Do not smoke or use other ignition sources near the cabinet. E.g. no hot work, such as welding.
HEALTH HAZARDS	The cleaning solvent used will contain substances hazardous to health, typically acetone, methanol, white spirit, xylene and toluene. Air monitoring carried out with a recommended cleaning thinner has shown that concentrations do not exceed exposure limits. Levels were less than 50% of the mixed short-term exposure limit when the lid was open for removal of the spray gun, cups and hoses and just 6% of the limit during the cleaning cycle. Substances in the solvent however can be absorbed through the skin, see personal protection equipment.
VENTILATION	A local exhaust ventilation system as supplied with the machines, should be installed so that vapours are safely vented to atmosphere away from windows and other air inlets.
PERSONAL PROTECTION EQUIPMENT	Suitable gloves must be worn when replacing and removing spray guns from the cleaning machine. Most glove manufacturers recommend Nitrile gloves for the solvent xylene and toluene, which can be absorbed through the skin.
WASTE DISPOSAL	Waste solvent must be removed by a registered carrier to a disposal or recovery facility licensed to receive waste solvent.
EMERGENCY ACTION	In case of fire, use a form of dry powder extinguishing agent. Cool solvent drums exposed to fire with water spray.  FIRST AID  Eye contact with solvent- irrigate with clean water. Skin contact with solvent remove contaminated clothing, wash skin thoroughly with soap and water. Excess inhalation of solvent vapours – Remove to fresh air, seek medical attention  Accidental Ingestion – Do not induce vomiting, seek medical attention.  SPILLAGE OF SOLVENT  Contain and collect with non-combustible materials E.g. sand and earth. Do not allow to enter drains. Exclude sources of ignition. Ventilate area.





# **AIR PIPING CIRCUIT**




# **TECHNICAL SPECIFICATIONS**

Part #	Description
Washing Station(s)	1 Manual
Washing Station Capacity	1 Paint Gun / 1 Cup
Dimensions (H x W x D)	60" X 21" X 15 ¾"
Weight	104 lb
Air input	76/100 psi
Air input connection	1/4" NPT
Warranty Parts / Pump	2 years / 5 years
Product No.	350300





# **EXPLODED VIEW & PARTS LIST**



(		13/14/
ID	Part #	Description
1	NPN	Silver Door Handle
2	NPN	Fixing Cap
3	NPN	Gas Strut 110 N
4	NPN	Gas Strut Bracket
5	324824	Fume Extractor
6	324835	8 mm Air Hose for Fume Extractor (sold by foot)
7	NPN	Wash Block
8	NPN	½"FFAdaptorwwy
9	NPN	½″ BSP Hose Tail
10	324817	1" Corrugated Hose for Drain (sold by foot)

П	D	Part #	Description
1	1	324838	48 mm Self Leveling Feet
1	2	324842	½"Corrugated Hose for Suction
1	3	324803	Pail Suction Filter
1	4	NPN	Nylon Tube
1	5	324812	Blue Filter Kit with 2 Filter Cartridges
1	6	324840	O-Ring for Blue Filter 324812
1	7	324815	10 Micron Filter Cartridge (Pack of 5)
1	8	324834	Blue Filer Housing
1	9	324839	Clamping Tool for Blue Filter
2	0	324830	On/Off Valve
2	1	324800	Husky 205 Pump
2	2	329826	50 psi Pressure Regulator (for Blow Gun)
2	3	324843	Gunwash Pressure Regulator & Gauge
2	4	324821	Complete Air Gun with Tip
2	5	324806	Nylon Trigger Clip (Pack of 5)
2	6	324614	Manual Flow-Thru Brush
2	7	324611	Heavy-Duty Brush Upgrade Kit (includes brush, hose, and couplings)
2	8	324822	Black Door Handle





# **LIMITED WARRANTY**

IST warrants all equipment led in this manual which is manufactured by IST and bearing its name, to be free from defects in material and workmanship on the date of sale by an authorized IST dristibutor to the original purchaser for use. Not with standing any special, extended or limited warranty published by IST will, for a period of TWELVE (12) months from the date of sale, repair or replace any part of the equipment determined by IST to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with IST's written recommendations.

This warranty does not cover, and IST shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non– IST component parts. Nor shall IST be liable for malfunction, damage or wear caused by the incompatibility with IST equipment with structures, accessories, equipment or materials not supplied by IST, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by IST.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized IST dristibutor for verification of the claimed defect. If the claimed defect is verified, IST will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser, transportation prepaid. If the inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

IST's sole obligation and the buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought forward within one (1) year of the date of sale.

IST MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY IST. These items sold, but not manufactured by IST (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. IST will provide the purchaser with reasonable assistance in making any claim for breach of these warranties.

#### LIMITATION OF LIABILITY

In no event will IST be liable for indirect, incidental, special or consequential damages resulting from IST supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of IST, or otherwise.

Report all accidents or "near misses" which involve IST products to :

- Technical Assistance

The following items are not covered under the IST warranty policy:

-Parts or chassis replacement due to normal wears.

Report all accidents or negligence involving IST products to our Service Department:

1877629-8202





# **WARRANTY REGISTRATION**

ISTpaint would like to thank you for your recent purchase of our product line. Please complete the card below and either mail or fax it to our office so that we may start the warranty of your product and keep you up to date on the EPA regulations by fax. Again, thank you for your purchase and if you have any suggestions or comments, please feel free to contact our office.

COMPANY NAME:  _ _ _ _ _ _ _ _ _
ADDRESS: IIIIIIIIIIIII
CITY:   _ _ _ _ _ _ _  STATE/PROV.: _ _ _ _ _
COUNTRY: IIIIIIIIPOSTAL/ZIP CODE: III III
CONTACT :
TEL. NUMBER:  _ _              -       FAX NUMBER:                   -
PURCHASE FROM:  _ _ _ _ _ _ _
DATE OF PURCHASE: II_  II   III   Month Day Year
SERIAL NUMBER:  _    -           -
TYPE OF FLUID USED:  _ _ _ _ _ _ _
Which factors most influenced your decision to purchase this ISTpaint unit?
SUGGESTIONS ABOUT THE EQUIPMENT:

IMPORTANT! Please complete and return within 30 days after purchase to activate the warranty.

PLEASE SEND THE COMPLETED FORM VIA EMAIL OR FAX TO: INFO@ISTSURFACE.COM OR 450-963-5122





### **INFORMATION / TECHNICAL ASSISTANCE**

# ISTpaint is a registered trademark of:



For more information, pricing or technical support, contact your local IST distributor or call / fax to our Consumer Information numbers:


TEL.: 1 877 629-8202 & 450 963-4400 FAX: 450 963-5122

Or visit us at: **istsurface.com** 





# **OUR MAP LOCATION**







# **ABOUT THE COMPANY**

#### **WHO WE ARE**

IST is a leading industrial manufacturer of standard and custom engineered equipment for the surface treatment industry and the solvent recycling industry.

#### **MISSION**

IST is dedicated to being an innovative and trusted supplier in the conception, fabrication and distribution of surface treatment equipment and recycling equipment.

The success of our mission relies on the following core values:

**Innovation - Integrity - Quality** 

The products, technologies and industry expertise of IST are used in a wide range of manufacturing and industrial applications, including but not limited to:

- General Manufacturing
- Industrial Equipment
- Metal forming
- Aerospace and Aviation
- Rail and Transit
- Marine
- Automotive

- o Petroleum
- o Flexography (labelling) & Lithography
- Wood finishing
- Power & Energy
- o Pharmaceutical





